



#### Dear customer,

Thank you for purchasing SmartGlobe<sup>TM</sup> 3 by Oregon Scientific.

We hope that this product will help you and your family to learn more about the world we live in, and to develop and interest in geography, history, and in cultures around the world. As a truly international company, all of us at Oregon Scientific take a personal interest in designing products that help both children and adults understand more about our global neighbors. It is our goal that you will learn something new and inspiring that might change your perspective of the world. The SmartGlobe<sup>TM</sup> 3 can be continually updated by connecting the SmartGlobe<sup>TM</sup> 3 to the Internet via USB cable. As such, we hope that every day will bring a new adventure to your world using SmartGlobe<sup>TM</sup> 3.


# ·Table of Contents •

About Your SmartGlobe <sup>TM</sup> 3 Kit —	1
Getting Started  AC/DC adapter connection Auto off	3
Low battery indicator PC requirements Key functions	
Activities  Touch Compare Find Spanish activities	5
Passport to the World booklet	8
Sound Options  Built-in speaker Base speaker Headphones	8
Register Your SmartGlobe <sup>TM</sup> 3	9
Access code  SmartGlobe <sup>TM</sup> 3 PC program installation  Register and update your SmartGlobe <sup>TM</sup> 3	
How to Renew Your Internet Subscription	11


# About Your SmartGlobe<sup>TM</sup> 3 Kit

Your  $SmartGlobe^{TM}\ 3$  is supplied with the following parts; please contact Oregon Scientific if any parts are missing.

### Front



### Back



# **Getting Started**

Your SmartGlobe<sup>TM</sup> 3 base uses four AA alkaline batteries, which are installed in the back of the base as shown. It is also equipped with an AC/DC adapter connection, which allows the base speaker to work without batteries.

Your smart pen uses two AAA alkaline batteries. To open the battery cover, remove the screw on the back of the pen with a coin and then pull it open from the top as shown. Once you have installed the batteries in the pen, remove the plastic tag from the back of the pen located next to the reset button. The tag is only for

Turn on the smart pen by pressing the **b** button.

#### AC/DC adapter connection

Please remove the batteries from the base unit before plugging in the AC/DC adapter. Otherwise the unit may be damaged. Plug the adapter into the adapter jack (center positive type) at the rear side of the unit. Plug the adapter into a wall outlet.

#### Auto off

The smart pen will automatically shut off after a few minutes if it is not being used, and the base speaker can only be used when plugged into the smart pen.

#### Low battery indicator

A flashing red LED light indicates that the smart pen is running out of batteries.

Note: The clock in smart pen will be inaccurate when out of batteries for over 2 minutes.

# **Caution**

- Different types of batteries or new and used batteries are not to be mixed.
- Only batteries of the same or equivalent type as recommended are to be used.
- Batteries are to be inserted with the correct polarity.
- Remove batteries from the unit if the unit is not going to be used for a long time. Remove all batteries when replacing.
- Do not dispose of batteries in fire.
- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed
- from the product before being charged. Rechargeable batteries are only to be charged under adult supervision
- Exhausted batteries are to be removed from the product.
- The supply terminals are not to be
- short-circuited.
  The base unit must not be connected to a
- power supply greater than 6V. Due to AC/DC adapter connection Not suitable for children under 3 years of age. Use only under adult supervision
- The Toy must only be used with the recommended adaptor.













- The transformer is not a toy. In an environment prone to static discharge, the unit may malfunction. To reset, remove batteries or disconnecting the adaptor for at least 10 seconds before
- connecting the power supply again.

  A toy transformer shall be provided with instructions that are easily understood by children of the ages for which the product is intended. The instructions shall describe the pr and care of the toy
- The instructions shall also contain a statement addressed to parents recommending that the toy transformer be periodically examined for conditions that may result in the risk of fire, electric shock, or injury to persons (such as damage to the output cord, blades, housing, or other parts) and that, in an event of such conditions, the transformer should not be used until properly repaired. toys liable to be cleaned with liquid are to be disconnected from the transformer before cleaning

#### PC requirements

- Windows Vista/XP
- 1 GHz or above 32-bit (x86) processor
- 512 MB RAM or above
- 50 MB of available hard disk space
- CD or DVD-ROM drive
- USB port
- Internet Access

## **Key functions**

#### Player

Touch this icon to select up to four players in the "Find" activities.

Touch this icon if you would like to pause the game. Touch it again to resume your game.

Touch this icon to repeat a question or instruction prompt.

#### Volume

To raise the volume, touch [ + ] To lower the volume, touch [ - ]

#### Demo

Touch this icon to listen to a demonstration of some of the exciting features and games on your SmartGlobe™3.

#### Local Map

To use the U.S. map, push in the drawer at the bottom of the base and it will open out, enough for you to pull it out by its sides. To close the drawer, push it back in until it clicks again.











# **Activities**

#### **Touch**

To learn about a country, use the tip of the smart pen to touch one of the 'Touch' categories on the activity panel (located on the base), and then use the smart pen to point to a place on the globe. To learn more about a particular country, use the smart pen to touch a different category on the activity panel, and touch the country again.

TOUCH		
Continent	Time	Weather
Name	Area	Features
Capital	Highest Point	History
Leader	Geography	Language
Population	Currency	National Anthem

# **Compare**

To compare information between two places, such as distances, flying times, and exchange rates, choose a category under 'Compare,' and then touch two countries on the globe one after the other. The smart pen will even let you compare places on the U.S. map with places on the main Globe.

Note: The time function will only be accurate once you have registered and updated the smart pen; see pages 9 and 10 for instructions. Also, the exchange rates will be based on those automatically updated at the time of your last download.

Compare
Population
Area
Currency
Time
Distance
Flying Time

# Find

To play a search game, touch one of the 'Find' categories with your smart pen. The SmartGlobe<sup>TM</sup> 3 will tell you to find certain places on the map, and you must answer the questions as quickly as you can. Each activity has 3 different levels, and for each level the player must answer the required number of questions correctly. Players need to answer the questions within the time limit; the time limit varies depending on the age group the player has selected. The 'Ultimate Challenge' game is a combination of questions from all the other categories.

Find
Continents
Countries
Capitals
Cities
Local Places
Ultimate Challenge

Note: Use the local map to answer the questions about local places.

This table shows the time limit of each game for each age group.

Game/Age	Age 5-8	Age 9-14	Age 15+
Continents	90 seconds	60 seconds	45 seconds
Countries	120 seconds	90 seconds	60 seconds
Capitals	120 seconds	90 seconds	60 seconds
Cities	120 seconds	90 seconds	60 seconds
Local Places	120 seconds	90 seconds	60 seconds
Ultimate Challenge	120 seconds	90 seconds	60 seconds

This table shows the number of correct answers required from the player to advance to a higher level.

			•
Age/Level	Age 5-8	Age 9-14	Age 15+
Level 1	1 question	2 questions	2 questions
Level 2	2 questions	2 questions	3 questions
Level 3	3 questions	3 questions	3 questions

5

# Spanish Activities (ESPAÑOL)

To learn about a country in Spanish, use the tip of the smart pen to touch one of the 'ESPAÑOL' categories on the activity panel (located on the base), and then use the smart pen to point to a place on the globe or the local map. To learn more about a particular country in Spanish, use the smart pen to touch an activity under the 'ESPAÑOL' category, and touch the country again.

Continente	(Continent)
Nombre	(Name)
Capital	(Capital)
Líder	(Leader)
Características	(Feature)
Hora local	(Time)

Knowledge

For up-to-date World News, Amazing Facts and Earth Facts, touch an icon with the smart pen under the 'Knowledge' column.

#### **Earth Facts**

Each time you select the Earth Facts icon, you will hear facts about the Earth.

#### **Amazing Facts**

To explore amazing facts in our world, use the tip of the smart pen to touch Amazing Facts on the activity panel (located on the base), and then use the smart pen to point to a place on the globe.

#### World News

Each time you select the World News icon, you will hear up-to-date World News. Updates are available; see "Register and update your SmartGlobe<sup>TM</sup> 3" on the page 9 and 10 for details.

Passport to the World booklet

Passport to the World is packed with colorful illustrations and the bonus audio allows for a deeper exploration of the world we live in. Use the tip of the smart pen to touch a picture in the booklet and hear content.

The booklet includes the following topics:

- Animals
- Food
- Landmarks
- Inventions and Innovations
- Dinosaurs
- Climate Change
- World History
- World Flags

Note: The booklet currently only supports English (US). Other language versions downloaded onto the smart pen are not compatible with the booklet at this moment, but the program will inform you when booklets of other languages are available.

# **Sound Options**

Your SmartGlobe<sup>TM</sup> 3 can be used in three different sound modes:

# **Built-in speaker**

With the smart pen's built-in speaker.

#### Base speaker


With the larger, louder speaker in the base; just use the speaker cable to connect the pen to the speaker jack.

#### **Headphones**

With headphones connected to the smart pen.

Note: Purchasing multiple smart pens allows multiple users to learn with one SmartGlobe<sup>TM</sup> 3 at one time; we recommend using headphones in this case.







# Register Your SmartGlobe<sup>TM</sup> 3

Your new SmartGlobe<sup>TM</sup> 3 is not only ready to be used right out of the box, but can also be customized by age level and can receive new educational content updated by Oregon Scientific editors.

Note: It is recommended that you register your SmartGlobe<sup>TM</sup> 3 in order to download the latest information for your Globe.

#### Access code

Your SmartGlobe<sup>TM</sup> 3 has a personal access code (located on this page and the back of CD-ROM cover) that will allow you to use our Internet services, which are free for one year from the time you begin using them. But before you get started, you need to register and activate the access code. The condition of this free service is that you must register the SmartGlobe<sup>TM</sup> 3 within 12 months after buying the SmartGlobe<sup>TM</sup> 3.

# SmartGlobe<sup>TM</sup> 3 PC program installation

Windows Vista and Windows XP

Note: Before the installation, please connect your PC to the internet.

- 1. Insert the **SmartGlobe**<sup>TM</sup> **3** CD-ROM into the disc drive of your PC.
- 2. A window will pop up, and the program will guide you through the installation process.
- \*If the window does not pop up, you can download the latest program at the following website: http://smartglobe3.oregonscientific.com/updates/usversion.html
- 3. After the installation process, connect the smart pen to your computer using the USB cable provided.
- 4. Your PC will recognize the smart pen and complete the driver installation.

Register and update your SmartGlobe<sup>TM</sup> 3

- 1) After the installation, a web page will open up; please fill in the information and enter the Access Code (located on page 9 and the back of the CD-ROM cover).
- 2) You can now download the latest information from our server. Follow the on-screen instructions on the PC control panel to update your SmartGlobe<sup>TM</sup> 3.

For further updates, click on the Oregon Scientific logo on your toolbar and follow the directions on your screen. Through our server, you will be able to change your age group, and download the latest information, including World News.

Note: Please turn off the Firewall before downloading the new data.

**Warning**: Do not unplug the smart pen while downloading the data otherwise it may damage the smart pen. Restart your PC or reinstall the download program if you encounter download failure several times.



- 1) Connect the smart pen to your computer using the USB cable provided.
  - 2) A panel will pop up.
  - 3) Select an age group and language. (Default is age 5-8, US English).
  - 4) Press the "Download" button to download the latest version from the Server.
  - 5) Unplug the smart pen when it shows "Download Completed".
  - \* As a result of our efforts to continually improve our products, the actual screen displays from the product may differ slightly from the diagrams shown.

0

# **How to Renew Your Internet Subscription**

Your SmartGlobe<sup>TM</sup> 3 purchase includes one year of free unlimited download service from the date of registration.

You will be reminded to renew your subscription 30 days before it expires.

Press the 'Renew now' button on the control panel window, and you will be directed to a web site through which you can renew your subscription.

#### **Cleaning and Maintenence**

Your smart pen and all cables should be checked regularly for damage to avoid the danger of an electric shock. Do not use them if they are damaged.

Always remove the batteries and disconnect the power supply before cleaning. Do not attempt to dismantle any part of the product, and only use a soft, dry cloth for cleaning.

Do not get SmartGlobe<sup>TM</sup> 3 or any of its parts wet, and be sure that your hands and the tip of the smart pen are clean before touching the globe surface; otherwise, the smart pen may fail to read information from the Globe.

#### **Contact Information**

As this product is updateable, prompts, instructions and game functions may change as we continue to improve SmartGlobe<sup>TM</sup> 3 and its user interface. We would be happy to receive your comments and suggestions, and appreciate your feedback. Feel free to contact us at smartglobe.us@oregonscientific.com.

Note: All SmartGlobe™3 data is for reference only, and is not intended to be used as a source for academic or professional research.

# Oregon Scientific, Inc.

19861 SW 95th Avenue Tualatin, OR 97062, USA Hotline: 1-800-853-8883 Website: www2.oregonscientific.com

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE:
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio or television recention, which can be determined by turning the equipment off If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio TV technician for help.

- "This Class B digital apparatus complies with Canadian ICES-003."
  "Cet appareil numérique de la class B est conforme à la norme NMB-003 du Canada"

 $WARNING\hbox{:}\ This\ product\ contains\ (a)\ small\ magnet(s).\ Swallowed\ magnetscan\ stick$ together across intestines causing serious infections and death. Seekimmediate medical attention if magnet(s) are swallowed or inhaled.



DISPOSAL

Do not dispose this product as unsorted municipal waste. Collection of such waste separately for special treatment is necessary

SAP: 3001000798

11